



How to hide all footprints: Use following regex in <https://regexr.com/>:
 (\fp_text reference [A-Za-z0-9\\$\%&*\{\}\[\]\^~\.\|"\'-])*(\{\w\d-\.\s\}*)*(layer F.SilkS)

USB Differential Pair:
 90 Ohm differential Impedance
 Substrate height: 109 um
 Substrate E_r: 4.2
 Conductor Thickness: 42 um
 Silk Screen height: 20 um (conductor), 40 um (PCB)
 Spacing: 120 um
 Width: 135 um

Top: SMD parts, Signals
 In1: Global GND Plane + Quarz Shield (separated)
 In2: Local 3V3 Plane (uC) + Signals
 In3: Local GND Plane (uC) + Signals
 In4: Global 3V3 Plane
 Bottom: 5V Network, Signals